

R/STX REVERSIBLE GEARBOX KIT [A310, A311, A314, A315] INSTALLATION INSTRUCTIONS

Note: During assembly, ensure the reversible gearbox components do not interfere with any other auger components.

Refer to Figure 1 and Figure 2 for assembly detail.

- 1. If present, remove the existing non-reversible gearbox from the auger.
- 2. Install the new reversing gearbox, chain coupler, and belt pulley as detailed in the auger assembly manual. Be sure to reattach all guards.
- 3. Loosely install the shift lever half-clamp pair (5) on the auger tube.
- 4. Use the gearbox shifter (6) to move the gearbox into either forward or reverse position.
- 5. Move the shift lever (4) to the same position as the gearbox shifter (forward or reverse). Ensure the detent pin (3) is engaged with the bracket.
- 6. Thread the adjustment lug (2) roughly halfway into the shift tube (1).
- 7. Connect the bent end of the shift tube to the gearbox shifter. This joint must pivot — do not over-tighten.
- 8. Loosely attach the other end of the shift tube to the shift lever.
- 9. Ensure the shift lever half-clamp bracket is centered on the auger tube. Adjust the half-clamps as required, then secure them to the tube by tightening the two 7/16" half-clamp bolts.
- 10. Disengage the detent pin and move the shift lever from forward to reverse a few times.
 - Ensure the gearbox fully engages in both directions when moving the lever back and forth.
 - The gearbox should be fully engaged when the detent pin is in the hole.
- 11. If the gearbox does not shift evenly in both directions, use the adjust lug to increase or decrease the length of the shift tube as required.



PART NUMBER: 30972 R0 REVISED: 12/4/16




Figure 1 Upper Shift Tube Attachment