



CX3 Top-Drive Field Loader


Portable Grain Belt Conveyor Operator's Manual

This manual applies to:

Batco BCX³, Westfield WCX³, Hutchinson HCX³

1500 Series: 1539, 1544, 1549

Electric and Hydraulic Drives



LOOKING FOR PARTS?

Check out our online
Parts Catalog!



Read this manual before using product. Failure to follow instructions and safety precautions can result in serious injury, death, or property damage. Keep manual for future reference.

Part Number: 8210-00027 R1

Revised: April 2022

Original Instructions

This product has been designed and manufactured to meet general engineering standards. Other local regulations may apply and must be followed by the operator. All personnel must be trained in the correct operational and safety procedures for this product. Use the sign-off sheet below to record initial and periodic reviews of this manual with all personnel.

[illegible]

CONTENTS

1. Introduction	5
1.1 Serial Number Location	5
1.2 Intended Use	5
2. Safety.....	6
2.1 Safety Alert Symbol and Signal Words.....	6
2.2 General Safety Information.....	6
2.3 Overhead Power Lines	6
2.4 Moving Conveyor Belt Safety.....	7
2.5 Upending	7
2.6 Rotating Parts Safety.....	7
2.7 Work Area Safety	7
2.8 Guards Safety	9
2.9 Raising and Lowering the Conveyor.....	10
2.10 Hand Winch Safety.....	10
2.11 Positioning the Conveyor	10
2.12 Towing the Conveyor	10
2.13 Drives and Lockout Safety.....	11
2.13.1 Electric Motor Safety.....	12
2.13.2 Hydraulic Power Safety	13
2.14 Tire Safety.....	14
2.15 Personal Protective Equipment.....	14
2.16 Safety Equipment	15
2.17 Safety Decals	15
2.17.1 Decal Installation/Replacement.....	15
2.17.2 Safety Decal Locations and Details	16
3. Features.....	25
4. Transport.....	26
4.1 Transport Safety	26
4.2 Transport Preparation	26
4.3 Connecting the Conveyor to the Towing Vehicle	27
5. Placement	28
5.1 Placement Safety.....	28
5.2 Positioning the Conveyor	28
5.3 Hand Winch Operation.....	29
5.4 Collapsible Hopper Cloth Control.....	30
5.5 Conveyor Operating Angles	30
6. Operation	32
6.1 Operation Safety	32
6.2 Start-up and Break-in	32
6.3 Operation - Electric Motor Models	33
6.4 Operation - Hydraulic Motor Models	33
6.5 Loading Area.....	33
6.6 Conveying Fertilizer	34
6.7 Conveyor Belt Speed	36
6.8 Emergency Shutdown	36

6.9 Restarting with a Full Tube	36
6.10 Shutdown	36
6.11 Storage.....	37
7. Maintenance	38
7.1 Maintenance Safety	38
7.2 Maintenance Schedule.....	38
7.3 Visually Inspect the Equipment.....	39
7.4 Lubricate the Equipment.....	40
7.5 Oil the Chain Coupler	40
7.6 Inspect Hydraulic Hoses and Fittings	40
7.7 Inspect the Hopper Flashing	41
7.8 Check the Roller Bearings	41
7.9 Check the Rollers.....	41
7.10 Tension the Conveyor Belt.....	41
7.10.1 Top Drive Pinch Roller.....	42
7.11 Align the Conveyor Belt.....	43
7.11.1 Adjust the Rollers	44
7.11.2 Adjust the Belt Return Wear Blocks.....	45
7.12 Inspect Belt Lacing.....	45
7.13 Replace the Belt Lacing	46
7.14 Replace the Conveyor Belt.....	47
7.15 Replace the Transition Seals	48
7.16 Clean and Wash the Equipment	50
7.17 Tension the Drive Belts	51
7.18 Align the Drive Belts.....	52
7.19 Replace the Drive Belts	52
7.20 Repack the Wheel Bearings with Grease.....	52
7.21 Inspect and Service the Hand Winch and Lift Cable.....	53
8. Troubleshooting.....	54
9. Specifications	57
10. Limited Warranty.....	58

1. Introduction

Thank you for your purchase. Follow the instructions in this manual for safe use of this conveyor. Following proper operation and maintenance will help to keep the conveyor running in optimal condition.


Keep this manual handy for frequent reference and to review with new personnel. A sign-off form is provided on the inside front cover for your convenience. If any information in this manual is not understood or if you need additional information, please contact AGI or your representative for assistance.

This manual should be regarded as part of the equipment.

1.1. Serial Number Location

The serial number location for your conveyor is shown in the figure below. Have the serial number ready when ordering parts or requesting service or other information. Record information in the table below for easy reference.

Model Number	
Serial Number	
Date Received	



1.2. Intended Use

- Handling grain, pulse crops, treated seeds, or other similar materials.
- Handling fertilizer when specific operating and cleanout procedures are followed.

Misuse

Do not install/use the conveyor for/with:

- transferring material other than dry, free-flowing food-grains.
- lifting or using as a hoist or crane.

2. Safety

2.1. Safety Alert Symbol and Signal Words



This safety alert symbol indicates important safety messages in this manual. When you see this symbol, be alert to the possibility of injury or death, carefully read the message that follows, and inform others.

Signal Words: Note the use of the signal words **DANGER**, **WARNING**, **CAUTION**, and **NOTICE** with the safety messages. The appropriate signal word for each message has been selected using the definitions below as a guideline.



Indicates an imminently hazardous situation that, if not avoided, will result in serious injury or death.



Indicates a hazardous situation that, if not avoided, could result in serious injury or death.



Indicates a hazardous situation that, if not avoided, may result in minor or moderate injury.



Indicates a potentially hazardous situation that, if not avoided, may result in property damage.

2.2. General Safety Information

Read and understand all safety instructions, safety decals, and manuals and follow them when operating or maintaining the equipment.

- Owners must give instructions and review the information initially and annually with all personnel before allowing them in the work area. Untrained users/operators expose themselves and bystanders to possible serious injury or death.
- Use for intended purposes only.
- Do not modify the conveyor in any way without written permission from the manufacturer and is not covered by the warranty.
- Follow a health and safety program for your worksite. Contact your local occupational health and safety organization for information.
- Follow applicable local codes and regulations.



2.3. Overhead Power Lines



- When operating or moving, keep conveyor away from overhead power lines and devices.
- The conveyor is not insulated.
- Electrocution can occur without direct contact.



2.4. Moving Conveyor Belt Safety

WARNING


- DO NOT step on or touch moving conveyor belt.
- Shut off and lock out power to adjust, service, or clean.



2.5. Upending

WARNING

- Anchor intake end and/or support discharge end to prevent upending.
- Intake end must always have downward weight. Do not release until attached to tow bar or resting on ground.
- Do not raise intake end above tow bar height.
- Empty the conveyor and fully lower before moving.



2.6. Rotating Parts Safety

WARNING

- Keep body, hair, and clothing away from rotating pulleys, belts, chains, and sprockets.
- Do not operate with any guard removed or modified. Keep guards in good working order.
- Shut off and lock out power source before inspecting or servicing machine.



2.7. Work Area Safety

- Have another trained person nearby who can shut down the conveyor in case of accident.
- Do not allow any unauthorized persons in the work area.
- Keep the work area clean and free of debris.



Figure 1. Conveyor Work Area (Hydraulic Drive)

Figure 2. Conveyor Work Area (Electric Drive)

2.8. Guards Safety

WARNING

- Keep guards in place. Do not operate with guard removed.
- Do not walk on, step on, or damage guards.
- Lock out power before removing a guard.
- Ensure all guards are replaced after performing maintenance.

2.9. Raising and Lowering the Conveyor

WARNING

- Before raising/lowering/moving/adjusting the conveyor, make sure the area around the conveyor is clear of obstructions and/or untrained personnel. Never allow anyone to stand on or beneath the conveyor when it is being placed.
- Lower the conveyor to its lowest position when not in use.
- Empty the conveyor before raising or lowering.
- Do not get on or beneath the conveyor when raising or lowering.
- Raise and lower conveyor on reasonably level ground only.
- Never attempt to increase height of the conveyor by positioning wheels on lumber, blocks, or by any other means. To do so will result in damage to conveyor and/or serious injury.
- Do not raise the conveyor in high winds.

2.10. Hand Winch Safety

WARNING

When Equipped:

- Inspect lift cable before using. Replace if frayed or damaged. Make sure lift cable is seated and tracking properly and cable clamps are secure.
- Tighten brake lock by turning winch handle clockwise at least two clicks after lowering the conveyor.
- Lower the conveyor fully before towing, then rotate winch handle until cable has light tension.
- Do not lubricate winch brake discs.

2.11. Positioning the Conveyor

WARNING

- Transport and place equipment on reasonably level ground when raising, lowering, positioning, or operating.
- Move the conveyor into position slowly. Do not unhitch and attempt to move by hand.
- Chock wheels and anchor intake end after placement.

2.12. Towing the Conveyor


The conveyor is not intended for transport on public roads. If it requires transport on a public roadway, the following steps should be taken:

WARNING

- Check with local authorities regarding transport on public roads. Obey all applicable laws and regulations.
- Always travel at a safe speed, never exceeding 20 mph (32 km/h).
- Reduce speed on rough surfaces.
- Do not transport on slopes greater than 20°.
- Use caution when turning corners or meeting traffic.
- Make sure the SMV (slow moving vehicle) emblem and all the lights and reflectors that are required by local authorities are in place, are clean, and can be seen by all over-taking and oncoming traffic.
- Always use hazard-warning flashers on tractor/towing vehicle when transporting unless prohibited by law.
- Do not allow riders on the conveyor or towing vehicle during transport.
- Attach to towing vehicle with an appropriate pin and retainer. Always attach safety chains.
- Place the conveyor in the transport position before moving on roads.

2.13. Drives and Lockout Safety

Inspect the power source(s) before using and know how to shut down in an emergency. Whenever you service or adjust your equipment, make sure you shut down the power source and unplug or remove the key (as applicable) to prevent inadvertent start-up and hazardous energy release. Know the procedure(s) that applies to your equipment from the following power source(s). Ensure that all personnel are clear before turning on power to equipment.



2.13.1 Electric Motor Safety




WARNING Power Source

- Electric motors and controls shall be installed and serviced by a qualified electrician and must meet all local codes and standards.
- Use a magnetic starter to protect the electric motor.
- You must have a manual reset button.
- Reset and motor starting controls must be located so that the operator has full view of the entire operation.
- Locate main power disconnect switch within reach from ground level to permit ready access in case of an emergency.
- Motor must be properly grounded.
- Ensure electrical wiring and cords remain in good condition; replace if necessary.

Lockout

- The main power disconnect switch should be in the locked position during shutdown or whenever maintenance is performed.
- If reset is required, disconnect all power before resetting motor.

SERVICE DISCONNECT



2.13.2 Hydraulic Power Safety

WARNING Power Source

- Refer to the rules and regulations applicable to the power source operating your hydraulic drive.
- Do not connect or disconnect hydraulic lines while system is under pressure.
- Keep all hydraulic lines away from moving parts and pinch points.
- Escaping hydraulic fluid under pressure will cause serious injury if it penetrates the skin surface (serious infection or toxic reaction can develop). See a doctor immediately if injured.
- Use metal or wood as a backstop when searching for hydraulic leaks and wear proper hand and eye protection.
- Check all hydraulic components are tight and in good condition. Replace any worn, cut, abraded, flattened, or crimped hoses.
- Clean the connections before connecting to equipment.
- Do not attempt any makeshift repairs to the hydraulic fittings or hoses with tape, clamps, or adhesive. The hydraulic system operates under extremely high pressure; such repairs will fail suddenly and create a hazardous and unsafe condition.

Lockout

- Always place all hydraulic controls in neutral and relieve system pressure before disconnecting or working on hydraulic system.



2.14. Tire Safety

WARNING

Failure to follow proper procedures when mounting a tire on a wheel or rim can produce an explosion that may result in serious injury or death.

- DO NOT attempt to mount a tire unless you have the proper equipment and experience to do the job.
- Have a qualified tire dealer or repair service perform required tire maintenance.
- When replacing worn tires, make sure they meet the original tire specifications. Never undersize the replacement tire.
- DO NOT weld to the tire rim with the tire mounted on the rim. This action may cause an explosion which could result in serious injury or death.
- Inflate tires to the manufacturer's recommended pressure.
- Tires should not be operated at speeds higher than their rated speed.
- Keep wheel lug nuts tightened to manufacturer's recommendations.
- Never reinflate a tire that has been run flat or seriously under-inflated without removing the tire from the wheel. Have the tire and wheel closely inspected for damage before remounting.



2.15. Personal Protective Equipment

The following Personal Protective Equipment (PPE) should be worn when operating or maintaining the equipment.

Safety Glasses

- Wear safety glasses at all times to protect eyes from debris.



Coveralls

- Wear coveralls to protect skin.



Hard Hat

- Wear a hard hat to help protect your head.



Steel-Toe Boots

- Wear steel-toe boots to protect feet from falling debris.



Work Gloves

- Wear work gloves to protect your hands from sharp and rough edges.



Dust Mask

- Wear a dust mask to prevent breathing potentially harmful dust.



2.16. Safety Equipment

The following safety equipment should be kept on site.

Fire Extinguisher

- Provide a fire extinguisher for use in case of an accident. Store in a highly visible and accessible place.



First-Aid Kit

- Have a properly-stocked first-aid kit available for use should the need arise, and know how to use it.



2.17. Safety Decals

- Keep safety decals clean and legible at all times.
- Replace safety decals that are missing or have become illegible. See decal location figures that follow.
- Replaced parts must display the same decal(s) as the original part.
- Replacement safety decals are available **free of charge** from your distributor, dealer, or factory as applicable.

2.17.1 Decal Installation/Replacement

1. Decal area must be clean and dry, with a temperature above 50°F (10°C).
2. Decide on the exact position before you remove the backing paper.
3. Align the decal over the specified area and carefully press the small portion with the exposed sticky backing in place.
4. Slowly peel back the remaining paper and carefully smooth the remaining portion of the decal in place.
5. Small air pockets can be pierced with a pin and smoothed out using the decal backing paper.

2.17.2 Safety Decal Locations and Details

Replicas of the safety decals that are attached to the conveyor and their messages are shown in the figure(s) that follow. Safe operation and use of the conveyor requires that you familiarize yourself with the various safety decals and the areas or particular functions that the decals apply to, as well as the safety precautions that must be taken to avoid serious injury, death, or damage.

Figure 3. Conveyor Safety Decal Locations




Figure 4. Electric Top Drive Safety Decal Locations





Figure 5. Hydraulic Top Drive Safety Decal Locations

Table 1. Safety Decals



Part Number	Description
8110-00238	<div style="border: 1px solid black; padding: 10px;"> <div style="background-color: #0056b3; color: white; text-align: center; padding: 5px; font-weight: bold; font-size: 1.2em;">NOTICE</div>  <p>To prevent belt damage, the conveyor belt must be tensioned correctly and the take-up roller must be straight.</p> <p>DO NOT adjust belt tracking with the take-up roller.</p> <p>To tension the belt correctly:</p> <ol style="list-style-type: none"> 1. While the conveyor is running empty, adjust the nut on both sides of the hopper so that the edge of the pipe is visible through the cutout. 2. Keep the take-up roller straight by adjusting the nut so that the distance (X) is the same on both sides of the hopper. 3. To prevent threaded rod damage, adjust X evenly on both sides. Do not adjust more than 3" at a time per side. <p>See manual for complete instructions.</p> </div>
P1513037	<div style="border: 1px solid black; padding: 10px;"> <div style="background-color: #ff9900; color: black; text-align: center; padding: 5px; font-weight: bold; font-size: 1.2em;">  WARNING </div> <div style="text-align: center; padding: 10px;"> <p>TRANSPORT HAZARD</p> <p>To prevent serious injury or death:</p> <ul style="list-style-type: none"> • Securely attach equipment to vehicle with correct pin and safety chains. • Use a tow vehicle to move equipment. </div> </div>

Table 1 Safety Decals (continued)

Part Number	Description
P1513060	<div style="border: 1px solid black; padding: 10px;"> <div style="background-color: orange; text-align: center; padding: 5px;">  WARNING </div> <div style="display: flex; justify-content: space-around; align-items: center; padding: 10px;">   </div> <div style="text-align: center; padding: 10px;"> BELT AND ROLLER HAZARD To prevent serious injury or death: <ul style="list-style-type: none"> • Keep hands away from rotating rollers and moving conveyor belt. • Do not operate with any guard removed or modified. Keep guards in good working order. • Shut off and remove key or lock out power source before inspecting or servicing machine. </div> </div>
P1513045	<div style="border: 1px solid black; padding: 10px;"> <div style="background-color: orange; text-align: center; padding: 5px;">  WARNING </div> <div style="display: flex; justify-content: space-around; align-items: center; padding: 10px;">   </div> <div style="text-align: center; padding: 10px;"> OPEN BELT CONVEYOR To prevent death or serious injury: <ul style="list-style-type: none"> • DO NOT step on or touch moving conveyor belt. • Shut off and lock out power to adjust, service, or clean. </div> </div>

Table 1 Safety Decals (continued)




Part Number	Description
P1513001	<div data-bbox="362 275 1068 678">  WARNING </div> <div data-bbox="362 369 1068 678">   </div> <div data-bbox="386 699 1039 1623"> <p>To prevent serious injury or death:</p> <ul style="list-style-type: none"> • Read and understand the manual before assembling, operating, or maintaining the equipment. • Only trained personnel may assemble, operate, or maintain the equipment. • Children and untrained personnel must be kept outside of the work area. • Do not modify the equipment. Keep in good working order. • If the manual, guards, or decals are missing or damaged, contact factory or representative for free replacements. • Lock out power before performing maintenance. • To prevent equipment collapse or upending, support equipment tube while disassembling certain components. • Follow grain storage structure manufacturer's warnings when loading and unloading. • Electric motors must be grounded. Disconnect power before resetting overloads. </div>

Table 1 Safety Decals (continued)



Part Number	Description
P1513042	<div data-bbox="362 275 1070 674">  </div> <div data-bbox="526 695 907 737">UPENDING HAZARD</div> <div data-bbox="391 758 911 800">To prevent death or serious injury:</div> <div data-bbox="391 816 1040 1121"> <ul style="list-style-type: none"> • Anchor intake end and/or support discharge end to prevent upending. • Intake end must always have downward weight. Do not release until attached to tow bar or resting on ground. • Do not raise intake end above tow bar height. • Empty tube and fully lower before moving. </div>
P1513052	<div data-bbox="362 1213 1070 1633">  </div>

Table 1 Safety Decals (continued)




Part Number	Description
P1513039	<div data-bbox="362 275 1073 359">  CAUTION </div> <p data-bbox="386 373 1044 415">For proper raising and lowering of equipment:</p> <ul data-bbox="386 430 1044 741" style="list-style-type: none"> • After lowering equipment, always tighten brake lock by turning winch handle clockwise at least two clicks. • Rotate winch handle until cable has light tension, when in towing position. • Do not lubricate winch brake discs. • Inspect lift cable periodically; replace if damaged. • Inspect cable clamps periodically; tighten if necessary.
P1513003	<div data-bbox="362 831 1073 915">  DANGER </div> <div data-bbox="362 915 1073 1234">  </div> <div data-bbox="362 1234 1073 1659"> <p data-bbox="459 1255 971 1297">ELECTROCUTION HAZARD</p> <p data-bbox="386 1318 914 1360">To prevent death or serious injury:</p> <ul data-bbox="386 1375 1011 1501" style="list-style-type: none"> • When operating or moving, keep equipment away from overhead power lines and devices. • Fully lower equipment before moving. <p data-bbox="386 1522 873 1564">This equipment is not insulated.</p> <p data-bbox="386 1585 1044 1627">Electrocution can occur without direct contact.</p> </div>

Table 1 Safety Decals (continued)





Part Number	Description
P1513008	<div data-bbox="362 275 1068 678">  </div>
P1513035	<div data-bbox="362 730 1068 1543">  </div>

Table 1 Safety Decals (continued)

Part Number	Description
P1513009	<div><div><div>WARNING</div><div>ELECTROCUTION HAZARD To prevent serious injury or death:<ul style="list-style-type: none">• Only qualified personnel should service electrical components.• Disconnect and lockout power before inspecting or servicing unit.• Keep electrical components in good repair.</div></div></div>

3. Features



4. Transport



Before continuing, ensure you have completely read and understood this manual's Safety section, in addition to the safety information in the section(s) below.

4.1. Transport Safety

WARNING

- Check with local authorities regarding transport on public roads. Obey all applicable laws and regulations.
- Always travel at a safe speed, never exceeding 20 mph (32 km/h). Reduce speed on rough surfaces. Use caution when turning corners or meeting traffic.
- Yield to other drivers and allow faster traffic to pass.
- Make sure the SMV (slow moving vehicle) emblem, maximum transport speed sign, and all the lights and reflectors that are required by local authorities are in place, are clean, and can be seen by all over-taking and oncoming traffic. Always use hazard-warning flashers on tractor/towing vehicle when transporting unless prohibited by law.
- Do not transport during times of limited visibility such as fog, snow, or heavy rain. Take extra precautions at night and at dusk.
- Keep others away from the transport vehicle and conveyor.
- Do not allow riders on the conveyor or towing vehicle during transport.
- Stay away from overhead obstructions and power lines when operating and transporting. Electrocution can occur without direct contact.
- Fully lower the conveyor before transporting, and only raise when next to storage facility.
- Attach to a proper towing vehicle with a hitch pin and retainer. Always attach safety chains.
- Do not raise the intake end above drawbar, upending may occur.
- Empty conveyor of all grain or seed before transporting. Transporting a full conveyor will place excessive loads on the tube, frame, axle, hitch, and tow vehicle.
- Do not transport on slopes greater than 20°.
- Do not transport with an under-inflated tire(s).
- If the conveyor wheels are partially or fully buried in snow or grain, failure to clear area around the wheels before transporting may cause damage to the conveyor or result in serious injury.

4.2. Transport Preparation

1. It is not recommended that the conveyor be transported faster than 20 mph (32 km/h). [Table 2](#) references the acceptable transport speed as per the ratio of tractor weight versus conveyor weight. See Specifications ([Section 9. – Specifications on page 57](#)) for conveyor weights.

WARNING

A weight imbalance between the conveyor and the towing vehicle could result in a collision from reduced stability, handling, and braking ability.

2. Ensure the conveyor will clear any overhead obstructions or electrical wires prior to transporting. Refer to [Section 9. – Specifications on page 57](#) for the transport height of your conveyor.

- Longer conveyors have a large turning radius. Allow ample room for turning as the discharge end may swing dramatically. Allow all oncoming traffic to pass before turning right or left.

**WARNING**

A collision with an oncoming vehicle could occur if the conveyor discharge swings into the opposing lane.

Table 2. Speed versus Weight Ratio

Road Speed	Weight of auger relative to weight of tow vehicle
Up to 32 km/h (20 mph)	1 to 1, or less than the weight of the tow vehicle
Up to 16 km/h (10 mph)	2 to 1, or less than the weight of the tow vehicle
Do not tow if	More than 2 to 1

4.3. Connecting the Conveyor to the Towing Vehicle

This section provides an overview of how to connect the conveyor to the towing vehicle. For specific information on the components, refer to the applicable section.

Follow all safety precautions when transporting the conveyor and use a proper towing vehicle.

- Fully lower the conveyor, there should be slight tension on the lift cable.
- Connect the conveyor to the tow vehicle with a hitch pin. Use a hitch pin that will not allow the conveyor to separate from the towing vehicle.
- Connect a safety chain securely, forming a cradle to prevent the conveyor from digging into the road surface (should a breakaway occur). Do not use the safety chain if one or more links or end fittings are stretched, broken, damaged, or deformed.

Important

Use a safety chain with a load rating at least as high as the conveyor weight.

- Use caution when transporting the conveyor over rolling terrain. In severe dips, the intake end may contact the ground.

Refer to [Section 9. – Specifications on page 57](#) for conveyor weight and hitch pin information.

5. Placement



Before continuing, ensure you have completely read and understood this manual's Safety section, in addition to the safety information in the section(s) below.

5.1. Placement Safety

WARNING

- The conveyor is not insulated, keep away from overhead power lines. Electrocution can occur without direct contact.
- Anchor intake end before using.
- Place the conveyor on reasonably level ground before operating. The conveyor could topple if ground is too uneven.
- Chock the conveyor wheels after placement.
- Empty the conveyor before raising, lowering, or positioning.
- Check that wheels are free to move before raising or lowering the conveyor.
- Never attempt to increase height of the conveyor by positioning wheels on lumber, blocks, or by any other means.
- Do not permit anyone to stand beneath the conveyor when raising or lowering.
- Move the conveyor into position slowly. Do not unhitch and attempt to move by hand.
- Do not leave conveyor in raised position when not in use.

5.2. Positioning the Conveyor

To position the conveyor using a tractor:

Filling Bins

1. Back the conveyor up to the bin while it is in its lowered configuration.
2. Set the park brake on the tractor before dismounting.
3. Raise the conveyor so it clears the bin.
4. Slowly back the conveyor up until the outlet is over the opening in the bin.
5. Unhook the conveyor from the tractor and lower the intake end to the ground.




WARNING Upending hazard, do not hook or unhook hitch unless weight is down.

6. Slowly lower the conveyor spout to the bin.

NOTICE

Do not rest the spout or hood on the bin. This may cause hood or belt damage.

7. Remove the hitch from the conveyor to prevent interfering with other equipment.
8. Place chocks in the front and back of each wheel and anchor the intake end.

Figure 6. Typical Grain Conveyor Placement for Filling Bins**Under Hopper Bottom Bins**

1. Center the conveyor between the hopper bin's vertical legs.
2. Collapse the cloth hopper until the conveyor is fully positioned under the bin.
3. Move the conveyor into place. Do not allow the conveyor tube or components to contact the bin.
4. Raise the conveyor to the desired height.
5. Make sure that gravel is not jammed against the belt under the hopper.
6. Place chocks in the front and back of each wheel and anchor the intake end.

5.3. Hand Winch Operation

➡ When equipped with a Hand Winch:

Before using the hand winch, ensure that:

- the cable anchor on the winch drum is tight.
- all cable clamps are secure.
- the lift cable is seated in cable pulley.
- the cable is in good condition, if damaged, replace it immediately.
- there is a minimum of 3 cable wraps on the winch drum when the conveyor fully lowered.

To operate:


1. Turn the winch handle to raise and lower the conveyor. The winch must make a clicking sound when raising the conveyor. If clicking sound stops, retain grip on handle, lower the conveyor fully and repair winch.
2. When lowering, if the cable becomes slack before conveyor is in full down position, this indicates that the track shoe is stuck. To correct the problem, reverse the winch and raise the conveyor until the cable is taut and the track slides normally. Do not lubricate the winch brake discs.

- 3. After lowering the conveyor, always tighten the brake lock by turning the winch handle clockwise at least two clicks.
- 4. After lowering, rotate the winch handle until cable has light tension.

5.4. Collapsible Hopper Cloth Control

The conveyor is designed with a collapsible hopper cloth to allow it to go under low discharge units.

Move the control handle toward the hopper or intake to raise the hopper cloth, and move the handle toward the outlet or spout end to collapse the hopper cloth.



5.5. Conveyor Operating Angles

Some grains can be moved at steeper angles than others. Grain will roll back if the conveyor is positioned at an angle greater than the grains natural moving/piling angle (angle of repose). The following table indicates the maximum angle that different grain types can be moved.

To determine conveyor angle, use the angle guide decal on your conveyor.

Note
The lower the angle, the greater the capacity of the conveyor.




Table 3. Maximum Moving Angles for Grains

Grain	Maximum Conveyor Angle (degrees)	Grain	Maximum Conveyor Angle (degrees)
Flax	24	Wheat	26
Lentils	29	Alfalfa Pellets	34

Table 3 Maximum Moving Angles for Grains (continued)

Grain	Maximum Conveyor Angle (degrees)	Grain	Maximum Conveyor Angle (degrees)
Mustard	26	Barley	25
Canola	20	Canary Seed	26
Oats	28	Chickpeas	30
Peas	30	Corn	23
Rice	36	Shelled Corn (dry)	23
Rye	25	Shelled Corn (wet)	28
Soybeans	28	Cotton Seed	30-45
Sunflower	22	Durum	23
Triticale	23		

6. Operation



Before continuing, ensure you have completely read and understood this manual's Safety section, in addition to the safety information in the section(s) below.

6.1. Operation Safety



WARNING

- Keep away from rotating and moving parts, including the conveyor belt, drive components, shafts, and bearings.
- Do not enter the grain bin or truck while the conveyor is operating.
- Always operate with guards, covers, and shields in place.
- Have another trained person nearby who can shut down the equipment in case of accident.
- Keep the work area clear of bystanders.
- Keep the work area clean and free of debris.
- Ensure maintenance has been performed and is up to date.



Refer to your bin operation manual for specific operating and safety information for your bin.

6.2. Start-up and Break-in

Check the following during the first hours of operation.

1. Check that the conveyor intake and discharge areas are free of obstructions.
2. Check conveyor belt alignment to ensure preset alignment does not vary under loaded conditions. See Maintenance Section for alignment instructions.
3. Check the conveyor belt tension. See Maintenance Section for tension instructions.
- ➡ 4. **Electric Drive Models:** Check the drive belt tension and alignment. See Maintenance Section for instructions.
5. Check the pinch roller bearings on the top drive pinch roller are not tight.
6. Visually inspect the conveyor, see Visual Inspection in Maintenance Section.
7. Check tightness of all bolts/nuts, fasteners, and hardware (re-torque if necessary).
8. Start the conveyor and operate normally, refer to power source instructions for further detail.
9. Be aware of unusual sounds. If any are heard, determine the source and stop the conveyor. Lock out the power and correct the problem before resuming work. If you are unsure of the problem or procedure, contact your local dealer.
10. Do not run the conveyor for long periods of time without material on the conveyor belt because it increases wear. Try to run only when moving material.
11. Stop the conveyor when it is empty of grain, lower fully and lockout power.

Important

After the initial start-up and inspection, the conveyor should be shut down and visually inspected (see Maintenance Section) after approximately ten hours of operation.

6.3. Operation - Electric Motor Models

➡ When equipped with an Electric Motor:

1. Turn the electric motor on.
2. Run until the conveyor is empty.
3. Turn off motor and lock out power source.
4. Unplug the power cord, wrap around the equipment and secure to prevent dragging, especially when transporting or placing the conveyor.

6.4. Operation - Hydraulic Motor Models

1. Place all tractor controls in neutral.
2. Start the tractor and run at low idle.
3. Engage the tractor hydraulic control lever and increase the engine to desired speed.

Note

The correct operation of a hydraulic system is directly linked to the pump's ability to supply the correct oil flow and pressure. If you cannot obtain the correct belt speed, check with your dealer to ensure the power unit is delivering the correct oil volume and pressure.

4. Run until the belting is empty.
5. Reduce tractor engine speed to low idle.
6. Place hydraulic control lever in neutral.
7. Shut off engine and remove ignition key.
8. Disconnect hydraulic hoses, and wrap hose around frame to prevent dragging.


6.5. Loading Area

To achieve maximum capacity, feed material on the belt:

- until the material tube clearance is 1/2".
- in the same direction as the belt travels.

Do not:

- unload material into the transition area.
- flood feed the hopper.

Figure 7. Conveyor Loading Zone

6.6. Conveying Fertilizer

Fertilizer may be conveyed using the conveyor when operated at a reduced capacity and additional care is taken to thoroughly clean the conveyor after operation.

Important

Fertilizer weakens the belt lacing and warranty is void on all lacing used with fertilizer. The belt lacing may need to be replaced more often if you convey fertilizer.

Additional Operating Requirements

To prevent problems that can be caused by conveying fertilizer:

1. Do not allow fertilizer to fill over the edge of the belt. This will allow fertilizer to get under the belt and start building up.
2. Reduce the flow if the conveyor belt starts to slip. Denser fertilizers will slow the conveyor belt down due to the weight of the product. Too much material will cause the drive roller to slip and lead to additional wear on the roller.
3. Do not move fertilizer with your conveyor in humid, wet or rainy conditions. This will cause buildup of fertilizer under your conveyor belt.

Additional Clean-Out Procedures

Proper cleaning will help to ensure longer belt life and prevent excess rust formation.

1. Run conveyor empty at full speed for 5-10 minutes after conveying fertilizer. This will help ensure that any product that may be under the belt will be cleaned out and prevent build up.




WARNING Do not attempt to manually remove build-up while conveyor is running.

2. Run the belt at low idle and inspect for damage on the belt and lacing, such as notches or cut outs caused by mice and normal wear. Any damage on the belt may result in fertilizer getting under the belt creating a buildup. Consider replacing the conveyor belt if it is in poor condition. If equipped with an electric motor, inspect on the belt return side with the electric motor not running. Turn on the conveyor to expose the belt that was previously in the tube. Turn off the conveyor and inspect the belt on the belt return, along with the lacing.
3. Shutdown and lockout power to the conveyor and vacuum or sweep out any remaining fertilizer from the hopper.

4. If buildup is evident on or under the belt, remove the buildup to ensure proper operation of the conveyor. When necessary remove fertilizer buildup from under the belt by scraping and washing the belt. If equipped with the optional Turbo Clean Wash System, see [Section 7.16 – Clean and Wash the Equipment on page 50](#)

Figure 8. Fertilizer Buildup at Hopper Transition



6.7. Conveyor Belt Speed

The best results are obtained when the input drives are set to provide a conveyor belt speed of 540 ft/min.

Count the number of belt revolutions per minute to determine belt speed. Refer to [Section 9. – Specifications on page 57](#) for belt length.

Note

Use the connector splice as a reference when counting belt revolutions.

To calculate, for example, 600ft/min belt speed for a 47ft belt:

$$\frac{BeltSpeed}{BeltLength} = \frac{600}{47} = 12.76$$

Therefore, 12.76 or approximately 13 belt passes per minute will provide a 600ft/min belt speed.

6.8. Emergency Shutdown

In an emergency situation:

1. Stop or shut down the power source immediately and lock out all power.
2. Stop the flow of material (if applicable).
3. Ensure the machine components come to a stop before inspecting.
4. Correct the emergency situation before resuming work.

6.9. Restarting with a Full Tube

When the conveyor is shut down inadvertently or due to an emergency, the tube may still be filled with grain.

1. With the power source locked out, remove as much of the grain as possible from the tube and intake using a shop vacuum or other tool. Do not use your hands.

NOTICE

Starting under load may result in damage to the conveyor.

2. If guards or covers have been opened or removed, close or replace them before restarting the unit.
- ➡ 3. **Electric Drive Models:** It may be necessary to tighten the drive belts slightly to handle the heavier than normal loads.
- ➡ 4. **Hydraulic Drive Models:** Since the start-up torque loads are so much higher than normal when the conveyor belting is full, restart at low speed. Do not let the conveyor belt drive roller spin on the belt if conveying belt does not start moving immediately. This will damage the drive roller and conveying belt.
5. Once the conveyor has been started, you may resume normal operation.

6.10. Shutdown

When operation has been completed:

1. Once the conveyor is clear of grain, lock out the power source.
2. Lower the conveyor fully. See Raising and Lowering instructions.

3. Clean out any remaining grain from the conveyor with a vacuum or sweep out.
4. Clean the entire work area.
5. Remove anchors, supports, and chocks.

6.11. Storage

After the season's use, the conveyor should be thoroughly inspected and prepared for storage. Repair or replace any worn or damaged components and perform maintenance as described in the Maintenance Section to prevent any unnecessary downtime at the start of the next season.

To ensure a long, trouble-free life, this procedure should be followed when preparing the unit for storage.

1. Remove all residual material from the hopper and the tube.
2. Stop the machine with the belt lacing inside the tube. This helps prevent the lacing from rusting.
3. Wash the conveyor thoroughly using a water hose or pressure washer to remove all dirt, mud, debris, or residue.
4. Inspect all moving or rotating parts to see if anything has become entangled in them. Remove any entangled material.
5. Touch up all paint nicks and scratches to prevent rusting.
6. Check tire pressure and inflate. For inflation pressure, refer to [Section 9. – Specifications on page 57](#).
7. Inspect the conveyor for cracks, tightness of fittings and fasteners, hydraulic hose cracks (if applicable). Have required repairs performed to replace worn or damaged components.
8. Store in an area that is dry, level, free of debris, and away from human activity. Store inside if possible.
9. Cover the motor with waterproof tarpaulin if stored outside to protect from weather.
10. Chock wheels.
11. Support intake on blocks to eliminate prolonged contact with the ground.
12. Lower the conveyor fully for storage.

7. Maintenance



Before continuing, ensure you have completely read and understood this manual's Safety section, in addition to the safety information in the section(s) below.

7.1. Maintenance Safety


WARNING

- Keep components in good condition. Follow the maintenance procedures.
- Ensure the service area is clean, dry, and has sufficient lighting.
- Do not modify any components without written authorization from the manufacturer. Modification can be dangerous and result in serious injuries.
- Shut down and lock out power before maintaining equipment.
- After maintenance is complete, replace all guards, service doors, and/or covers.
- Use only genuine AGI replacement parts or equivalent. Use of unauthorized parts will void warranty. If in doubt, contact AGI or your local dealer.



Before attempting maintenance of any kind:

- Lower the conveyor fully.
- Chock wheels.
- Support tube if performing maintenance on the undercarriage assembly.
- **If equipped with hydraulics:** Before applying pressure to a hydraulic system, make sure all components are tight and that hoses and couplings are in good condition.




7.2. Maintenance Schedule

Proper maintenance habits mean a longer life, better efficiency, and safer operation. Please follow the Maintenance Schedule below. Keep good records of the hours the conveyor has been operated and the maintenance performed.

Daily:
Section 7.3 – Visually Inspect the Equipment on page 39
Section 7.4 – Lubricate the Equipment on page 40
Monthly:
Hydraulic Drive Models: Section 7.6 – Inspect Hydraulic Hoses and Fittings on page 40

Section 7.7 – Inspect the Hopper Flashing on page 41
Section 7.8 – Check the Roller Bearings on page 41
Section 7.9 – Check the Rollers on page 41
Section 7.12 – Inspect Belt Lacing on page 45
Annually:
Hydraulic Drive Models: Section 7.5 – Oil the Chain Coupler on page 40
Section 7.10 – Tension the Conveyor Belt on page 41
Section 7.11 – Align the Conveyor Belt on page 43
Section 7.16 – Clean and Wash the Equipment on page 50
2–3 Years:
Section 7.13 – Replace the Belt Lacing on page 46
As Required:
Electric Drive Models: Section 7.17 – Tension the Drive Belts on page 51
Electric Drive Models: Section 7.18 – Align the Drive Belts on page 52
Electric Drive Models: Section 7.19 – Replace the Drive Belts on page 52
Section 7.15 – Replace the Transition Seals on page 48
Section 7.20 – Repack the Wheel Bearings with Grease on page 52
Section 7.21 – Inspect and Service the Hand Winch and Lift Cable on page 53
Section 7.14 – Replace the Conveyor Belt on page 47

7.3. Visually Inspect the Equipment

 **WARNING** Lock out power before inspecting.

Check the following during a visual inspection:

1. Ensure all guards are in place and in good working order.
2. Examine the conveyor for damage or unusual wear.
3. Check tightness of bolts/nuts, fasteners, and hardware (re-torque if necessary).
4. Be sure all safety decals are in place and are legible.
5. Check that the discharge and intake area are free of obstructions.
6. Inspect all moving or rotating parts to see if anything has become entangled in them. Remove any entangled material.
- ➡ 7. **When equipped:** Inspect hydraulic hoses and fittings for leaks and wear. Fix or replace where necessary.
8. Check wheel bolts are tight and examine tires for gashes, uneven wear, or loss of air pressure. See [Section 9. – Specifications on page 57](#) for recommended tire pressure and torque information.
9. Check all operating, lifting, and transport components. Replace damaged or worn parts before using the conveyor.

10. Inspect the winch cable for fraying, kinking, unwinding, or other possible damage.

7.4. Lubricate the Equipment

1. Wipe the grease fittings with a clean cloth before greasing to avoid injecting dirt and grit.
2. Use a hand-held grease gun for all greasing.
3. If fittings will not take grease, remove and clean thoroughly.
4. Replace fittings if they are broken or will not accept grease.

Use SAE multi-purpose high-temperature grease with extreme pressure (EP) performance. SAE multi-purpose lithium-based grease is also acceptable.


Grease Locations

Apply grease to the conveyor at the roller bearings for the hopper and spout.

7.5. Oil the Chain Coupler

The chain coupler is located between the hydraulic motor and the conveyor's drive roller.

Figure 9. Chain Coupler Location



7.6. Inspect Hydraulic Hoses and Fittings

➡ When equipped:

1. Pressurize the system.

2. Using a piece of cardboard or wood, run it along the length of the hose and around all fittings.



WARNING Escaping hydraulic fluid under pressure will cause serious injury if it penetrates the skin surface.

3. Replace the hose or tighten/replace the fitting if a leak is found. For replacement hoses, refer to [Section 9. – Specifications on page 57](#).
4. Replace any hose that is badly cut, nicked, abraded, or is separating from the crimped end of the fitting.
5. Secure hoses to the machine.

7.7. Inspect the Hopper Flashing

Check hopper flashing for wear and replace any that are worn. Worn flashing will cause hopper leakage.

7.8. Check the Roller Bearings

Check the roller bearings for wear. Any rollers making noise, getting hot while running, or that give should be replaced.

7.9. Check the Rollers

Inspect the roller to see if it is showing signs of wear. Replace rollers that are worn.

NOTICE

Operating the conveyor with a damaged roller will result in a damaged conveyor belt.

7.10. Tension the Conveyor Belt

Adjusting your conveyor belt for proper tension helps to ensure trouble-free operation and long belt life.

The conveyor belt only needs to be tight enough to not slip on the drive roller. If the belt is too loose, it will slip on the drive roller making a noticeable sound, slowing the belt down.

The conveyor belt should not be easy to pull from the hopper transition sides, otherwise the belt will require tensioning.

NOTICE

To prevent damage to the belt and/or rollers:

Do not use the conveyor if the belt is slipping. This will damage the conveyor belt and/or the drive roller. In extreme cases, sections of burnt belt will have to be replaced. This type of damage is not covered by warranty.

Tension the conveyor belt correctly and keep the take-up roller straight. DO NOT adjust belt tracking with the take-up roller.

To set correct conveyor belt tension:

Use the hopper pretensioner assembly to set the belt tension.


1. While the conveyor is running empty, tighten the welded nut on the end of the threaded rod on both sides of the hopper so that the edge of the pipe is in line with edge of the cutout. Refer to [Figure 10 on page 42](#)

NOTICE

Alternate sides when adjusting the pretensioner for distances of more than 3". If one side is more than 3" behind or ahead of the other, damage to the threaded rod may occur.


2. Keep the take-up roller straight by adjusting the nut so that the distance (X) is the same on both sides of the hopper. Use a tape measure to verify. The conveyor belt should deflect 1-2" when pushed down with a 5 lb force, or be difficult to pull from the sides of hopper transition.
3. Check the belt tension by running the conveyor for one minute. If the conveyor belt is not slipping, then proceed to next step; otherwise repeat from step 1.
4. After the conveyor belt has been tensioned, check the alignment of all rollers, see [Section 7.11 – Align the Conveyor Belt on page 43](#).
5. If the conveyor belt is still loose after tensioning, the belt needs to be shortened or replaced (depending on wear).

Figure 10. Typical Hopper



7.10.1 Top Drive Pinch Roller

The pinch roller mount plate should always be set loose, allowing the spring to pinch the belt between the rollers. This should not normally require adjustment. Ensure the adjustment bolt is always tight against the spacer.



7.11. Align the Conveyor Belt


Basic Conveyor Belt Alignment:

The conveyor belt will run straight when all of the rollers are straight.

Loosen or tighten the adjustment bolt(s) to align the conveyor belt. Tighten the side the belt has moved toward, or loosen the side the belt has moved away from.

Belt alignment is done while the belt is running.

Figure 11. Roller out of Alignment




Before Aligning the Belt:

- The conveyor must be empty of all grain.
- Wait until the belt makes a complete revolution before adjusting the rollers. Some belts may have uneven edges, appearing misaligned.

To Align the Belt:


If your belt is tracking off-center, follow the sections and steps in the order following to center it.

Figure 12. Belt Tracking to One Side


**7.11.1 Adjust the Rollers**

1. Loosen bearing nuts and jam nuts (if equipped).

Figure 13. Loosen the Bearing Nuts




2. Rotate adjustment bolt 1/2 turn.

Figure 14. Rotate the Adjustment Bolt

3. Restart conveyor and run empty for 1 minute.
4. Stop the conveyor and remove ignition key or lock out the power source.
5. If the belt has centered, move to next step. If not, repeat Step 2 to Step 4 until the belt is centered.
6. Tighten the bearing bolts and jam nut (if equipped).
7. Replace any guards that were removed.

7.11.2 Adjust the Belt Return Wear Blocks

1. The edge of the conveyor belt should be positioned above the guide blocks and may wear a groove over time. If they are worn all the way down, rotate the wear blocks 90 or 180 degrees. Replace after all sides are worn.

Figure 15. Belt Return Wear Blocks

2. Replace the guards if removed.

7.12. Inspect Belt Lacing

Inspect the condition of the belt lacing, if any clips are worn through, replace all lacing.


7.13. Replace the Belt Lacing

1. Rotate the conveyor belt until the lacing is by the hopper or is easily accessible.
2. Loosen the tension on the take-up roller all the way.
3. Pull all the slack to the lacing area.
4. Remove the lacing retainer clip and pin.
5. Using a square and sharp knife, cut the lacing off right behind the lacing clips. The cut belt **MUST** have a square end.
6. Use a knife to cut Chevron pattern off 1" back from the end of the belt. This ensures that the lacing is centered and fully seated on the belt.
7. Count the lacing clips on the removed section and install the same number of new lacing clips with a lacing tool. Center the lacing on the belt and follow the lacing tool's instructions.
8. Align the conveyor belt ends and install the lacing pin.
9. Crimp the retainer clips onto each end of the lacing pin. Refer to [Figure 16](#).
10. Tighten the conveyor belt. Refer to [Section 7.10 – Tension the Conveyor Belt on page 41](#).
11. Check and set the belt alignment. Refer to [Section 7.11 – Align the Conveyor Belt on page 43](#).
12. Engage the conveyor drive. Allow the conveyor to run for 30 seconds, then shut down the conveyor and inspect the lacing.

7.14. Replace the Conveyor Belt

1. Rotate the conveyor belt until the lacing is by the hopper or is easily accessible.
2. Loosen the tension on the take-up roller all the way.
3. Pull all the slack to the lacing area.
4. Remove the lacing retainer clip and pin.
5. Attach one end of the replacement belt to the belt end being removed, closest to the hopper.
6. Pull the old belt out and the new belt will be threaded into place.
7. Disconnect the old belt.
8. Reattach conveyor belt ends together. If required, use a ratchet strap clamped to both ends of belt to cinch belting ends together.
9. Install the lacing pin and crimp the retainer clips onto each end of the lacing pin, see [Figure 16](#).
10. Remove the ratchet strap and tighten the conveyor belt. [Section 7.10 – Tension the Conveyor Belt on page 41](#).
11. Check and set the belt alignment. Refer to [Section 7.11 – Align the Conveyor Belt on page 43](#).
12. Engage the conveyor drive. Allow it to run for 30 seconds, then shut down the conveyor and inspect the lacing.
13. On both corners of the trailing edge of the belt, trim 1/8" off the tip of the corner to prevent ing.

Figure 16. Lacing the Conveyor Belt



7.15. Replace the Transition Seals

The transition seals need to be replaced if the conveyor is leaking material excessively from this area.

To replace the seals, the conveyor belt is removed from the hopper area. Then the bearings and rollers are removed before the seals are replaced.

Accessing the Seals

1. Rotate the conveyor belt until the lacing is between near the hopper.
2. Loosen the tension on the hopper take-up roller all the way.
3. Remove the lacing retainer clip and pin.
4. Pull the belt up through the transition so that the hopper is visible from the top and bottom of the conveyor.
5. Raise the hopper and support it underneath.

Replacing the Lower Transition Seal

Note

The lower transition seal is equipped on both Field Loader and CUB hoppers.

1. Remove the hardware (5, 7, 8) and bearings (4) and pull out the roller (1).
2. Remove the old seals (3) and put the new ones in place.
3. Re-install the roller (1) and bearings (4).

Replacing the Upper Transition Seal

Note


The upper transition seal is equipped on Field Loader hoppers only. They are not present on the CUB hoppers.

1. Remove the locking collars from the roller (1).
2. Remove the two bolts (5, 6) that hold each seal (2) in place and remove the seals.
3. Place the new seals in the hopper. Hammer the roller (1) to the opposite side of the hopper to get more room to position the new seals.
4. Re-center the roller (1).
5. Re-attach the locking collars.

Finishing Up

1. Thread the belt back through the hopper until the lacing is near the hopper.
2. Insert the lacing retainer clip and pin.
3. Remove the supports and lower the hopper back to the ground.
4. Tension the hopper take-up roller. Refer to [Section 7.10 – Tension the Conveyor Belt on page 41](#).

Figure 17. Transition Seals



7.16. Clean and Wash the Equipment

Clean out the conveyor after handling any product.

⚠ WARNING Failure to lock out power can cause severe injury.

Clean out and wash down the conveyor after operation prevents:

	Dry Grain	Fertilizer
Product build up	✓	✓
Roller misalignment	✓	✓
Excess belt wear/damage	✓	✓


Cleaning Out the Conveyor

1. Remove any product remaining in the hopper and spout with a vacuum or sweep out.
2. Remove debris from shafts, sheaves, and drive belts (as equipped).
3. Once the conveyor is clean, check for damage to the belt lacing and belt notches or cuts. Any damage to the belt may result in product getting under it creating a build-up. If belt replacement and re-lacing is necessary, refer to the Maintenance Section.
4. Once cleaned out, cover the hopper to prevent moisture from collecting.

Washing Down the Conveyor (if equipped with Turbo Clean Belt Wash System)

Do not wash down the belt if there is a chance of freezing temperatures as this will cause the belt to freeze to the tube.


1. Attach a garden hose to the spray tube (if equipped).
2. Run clean water through the spray tube for 15-20 minutes while running the belt at medium throttle.
3. If the belt has experienced excessive build up, check between the belt and the weather guards at the spout for buildup and manually clean out.
4. Monitor the belt tension while running empty. Refer to [Section 7.10 – Tension the Conveyor Belt on page 41](#).
5. Disconnect the garden hose and run empty for two minutes to clean out any remaining water.
6. Allow the conveyor belt to dry before using again.
7. Once the conveyor belt is washed, the capacity will be somewhat less once the belt has been cleaned and will increase after running a few loads of dry grain through the conveyor.

Figure 18. Turbo Clean Spray Tube Location

7.17. Tension the Drive Belts

➡ When equipped:

1. Remove guard and push on the center of the belt span with a force of approximately 5 lb. The belts will deflect approximately 1" (25 mm) when properly tensioned.

Figure 19. Typical Drive Belt Tensioning

2. Tighten or loosen the drive belts (or idler pulley when equipped) to achieve the proper tension.

Important

The drive belt should be just tight enough to not slip on the drive pulley when operating. If the belt is too loose, it will slip, possibly causing a squeaking sound and slowing the belt down. If the belt is too tight, it will cause excess wear.

3. Reattach and secure guard. Start system to ensure proper operation.

7.18. Align the Drive Belts

➡ When equipped:

1. Lay a straight edge across the pulley faces to check the alignment.
2. Use the pulley hub to move the pulley to the required position for alignment.
3. Tighten the hub bolts to secure pulley on the drive shaft.
4. Check the belt tension.
5. Reattach and secure the guard.

7.19. Replace the Drive Belts


➡ When equipped:

1. Remove the guard.
2. Fully loosen the drive belts.
3. Remove and replace the old belts.
4. Tighten the drive belts as described in Belt Tension.
5. Align the drive belts as described in Belt Alignment.
6. Reattach and secure the guard.


7.20. Repack the Wheel Bearings with Grease


1. Block wheels and ensure unit is stable.
2. Remove the wheel bolts and the wheels.
3. Clean wheel and hub mounting surfaces to ensure there is no rust or debris.
4. Remove the wheel bearing and pack with grease. Use SAE multi-purpose high-temperature grease with extreme pressure (EP) performance. SAE multi-purpose lithium-based grease is also acceptable.
5. Tighten the wheel bolts (diagonal pattern) with a torque wrench to 100 ft-lb (± 10 ft-lb) of torque. Inspect to make sure the wheel is sitting flush with the hub.

Figure 20. Diagonal Pattern for 4-bolt and 6-bolt Tires



7.21. Inspect and Service the Hand Winch and Lift Cable

 When equipped:

 **WARNING** Place conveyor in fully lowered position with cable slack.

1. Inspect the cable for damage such as fraying, kinking, or unwinding. Replace if damaged (see below).
2. Check to make sure cable clamps are secure.
3. Oil cable pulleys as needed.
4. Keep a film of grease on the gears. Occasionally oil the bushings, drum shaft, and ratchet.
5. Do not get oil or grease on brake discs.
6. Replace brake discs if less than 1/16" (1.6 mm) thick.
7. Check for proper ratchet pawl operation:
 - When cranking in (clockwise) = loud clicking
 - When cranking out (counterclockwise) = no clicking and ratchet pawl fully engaged into gear teeth.

To Replace the Lift Cable:

1. Unwind the winch drum until cable is slack and remove all cable clamps.
2. Free the cable from the winch and pulleys.
3. Remove the cable clamps that secure the hook in place.
4. Reverse the above steps to install the new cable.

8. Troubleshooting

⚠ WARNING Shut down and lock out all power sources before diagnosing any of the causes or attempting any of the solutions below.

In the following section, we have listed some causes and solutions to some of the problems you may encounter.

If you encounter a problem that is difficult to solve, even after having read through this section, please contact your local dealer or distributor. Before you contact them, please have this operation manual and the serial number from your machine ready.

Conveyor

Problem	Cause	Solution
Low conveying capacity.	Conveyor angle is too high.	Re-position with lower tube angle, see Operation.
	Incorrect belt speed.	Verify and adjust belt speed to appropriate speed, see Belt Speed in Operation.
	Conveyor belt slipping.	Tighten conveyor belt, see Conveyor Belt Tension in Maintenance.
	When equipped: Drive belts slipping.	Tighten belts, see Drive Belt Tension in Maintenance.
Low capacity for some grains.	Smaller and smoother grains will slide at shallower angles.	Reduce conveyor height, see Conveyor Operating Angles in Operation.
Conveyor belt slipping.	Conveying belt loose.	Tighten and align belt, see Belt Tension and Belt Alignment in Maintenance.
	Drive roller worn or damaged.	Replace drive roller, see dealer.
	When equipped: Drive belts loose.	Tighten belts, see Drive Belt Tension in Maintenance.
	Belt frozen to tube from operating in high humidity in cold conditions.	Remove conveyor from area of high humidity and warm belt to de-ice.
Excessive conveyor belt edge fraying.	Belt not aligned.	Align belt, see Belt Alignment in Maintenance.
Conveyor belt loose.	Belt stretches over time.	Re-tension belt, see Belt Tension in Maintenance.

Problem	Cause	Solution
		If belt is fully tensioned, you may need to shorten belt and re-lace, see Belt Relacing in Maintenance.
Grain leaking from conveyor hopper.	Belt not aligned (centered).	Align belt, see Belt Alignment in Maintenance.
	Flashing installed incorrectly or worn.	Inspect flashing for wear and replace if required.
	Hopper cloth worn or damaged.	Replace damaged hopper cloth.
	When equipped: Transition filler rings are worn.	Replace transition filler rings.
Hopper cloth collapsing under grain.	Misaligned or broken spring (s).	Check spring installation and repair as required.
	Pivot shafts improperly installed.	On some machines, switching pivot shafts left to right will increase hopper tension.
Grain leaking from conveyor discharge between belt and tube.	Belt not aligned (centered).	Align belt, see Belt Alignment in Maintenance.
Grain leaking from conveyor discharge between hood and belt.	Belt speed is too fast, hood plugging.	Decrease belt speed, see Belt Speed in Operation.
U-clamps or brackets sliding on tube.	U-clamps or brackets not properly crimped to tube.	Contact dealer or AGI to correct positioning.

Frame/Undercarriage with Hand Winch


Problem	Cause	Solution
The conveyor will not raise or lower.	The conveyor is already at its maximum or minimum height.	If at maximum height, lower the conveyor.
	Obstruction in the slide.	Clear the obstruction.
	Faulty cable.	Replace cable.

Problem	Cause	Solution
	Faulty winch.	Consult your local dealer.
	The bottom or top of the conveyor is obstructed.	Clear the obstruction.
The conveyor will not stay elevated.	Faulty winch.	Lower conveyor to transport position and repair or replace winch.

Drive

Problem	Cause	Solution
Drive making noise.	Electric Drive: Slipping drive belt.	Tighten belts, see Drive Belt Tension in Maintenance.
	Hot shaft, pulley or bearing.	Overheated components indicate a failed bearing that must be repaired.
	Broken drive roller.	Replace damaged component.

9. Specifications



FL Conveyors										
							Down – Transport	Up – Operation		
Part #	Model	Belt Length	Approx. Weight (without Drive)	Hitch Weight* (lbs)	A** (ft)	B (ft)	A** (ft)	B (ft)	Width (ft)	HP Elec
15503951	1539 FL	86'3"	1725	90	11.1	18	20.1	16.4	7.5	10
15504451	1544 FL	96'3"	1775	90	12.5	20.5	20.7	19.7	7.5	10/12.5
15504951	1549 FL	106'3"	1825	100	13.3	22.7	20.8	22.7	7.5	12.5

CUB Conveyors										
							Down – Transport	Up – Operation		
Part #	Model	Belt Length	Approx. Weight (without Drive)	Hitch Weight* (lbs)	A** (ft)	B (ft)	A** (ft)	B (ft)	Width (ft)	HP Elec
15503953	1539 CUB	81'3"	1575	90	11.3	16.1	15.1	19.1	7.5	10
15504453	1544 CUB	91'3"	1625	90	12.9	18.3	19.8	18.2	7.5	10/12.5
15504953	1549 CUB	101'3"	1675	100	13.1	20.4	19.5	21	7.5	12.5

*With AGI supplied electric motors.

**A in "Down - Transport" position is measured from the ground to the highest point on the conveyor, A in "Up - Operation" is measured from the ground to the bottom of the hood.

10. Limited Warranty

This warranty relates to Belt Conveyors (the “Product”) sold by AGI (referred to herein as the “Seller”) and applies only to the first user of the Product (meaning a purchaser directly from the Seller or from an authorized dealer or distributor of the Product, referred to herein as the “Buyer”).

This warranty shall only be effective if properly registered with the Seller in accordance with information provided to the Buyer at the time of sale.






1. The Seller warrants to the Buyer that the Product is free from defects in material and workmanship **under normal and reasonable use** and in accordance with manufacturer’s manual.
2. This warranty applies only to defects in materials and workmanship and not to damage incurred in shipping or handling, through normal wear and tear, or damage due to causes beyond the control of the Seller such as lightning, fire, flood, wind, earthquake, excessive voltage, mechanical shock, water damage, or damage arising out of abuse, alteration, improper assembly, improper installation, improper maintenance or improper repair of the Product.
3. **The warranty period for the Product shall be two years from delivery of the Product to the Buyer where the Product is used in a normal farm operation. First year of warranty coverage of parts and repair labour, second year warranty coverage of parts only. Warranty period for the Product shall be 90 days from delivery of the Product to the Buyer where the Product is used in a commercial operation. No warranty is given where the Product was used to convey canola.** In the event that any part incorporated into the Product is manufactured and sold to the Seller by a third party vendor, such part is only warranted to the extent of the warranty given by that third party.
4. This warranty does not obligate the Seller to bear costs of travel in replacing defective parts.
5. The obligations set forth in this warranty are conditional upon the Buyer promptly notifying the Seller of any defect and completing reasonably required documentation and, if required, promptly making the Product available for correction.
6. The total liability of the Seller on any claim, whether in contract, tort or otherwise, arising out of, connected with, or resulting from the manufacture, sale, delivery, repair, replacement or use of the Product or any part thereof **shall not exceed the price paid for the Product** and the Seller shall not be liable for any special indirect, incidental or consequential damages caused by reason of the installation, modification, use, repair, maintenance or mechanical failure of the Product. **Consequential or special damages as used herein include, but are not limited to, lost or damaged products or goods, costs of transportation, lost sales, lost orders, lost income, increased overhead, labor and incidental costs and operational inefficiencies.**
7. The foregoing warranty is the entire warranty of the Seller to the Buyer and the Buyer shall not be entitled to rely upon any representation or warranty contained in any marketing material of the Seller in respect of the Product. The Seller neither assumes, nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning the Product.

WARRANTY VOID IF NOT REGISTERED

AGI is a leading provider of equipment solutions for agriculture bulk commodities including seed, fertilizer, grain, and feed systems with a growing platform in providing equipment and solutions for food processing facilities. AGI has manufacturing facilities in Canada, the United States, the United Kingdom, Brazil, South Africa, India and Italy and distributes its products globally.



201 Industrial Drive, Swift Current, Saskatchewan, Canada S9H 5R4
P 877.667.7421 (Canada & USA) or 306.773.7779 | F 306.778.2524 | E sales@batco-rem.com |
aggrowth.com/batco

AGGROWTH.COM [aggrowthintl](http://aggrowthintl.com)     

©Ag Growth International Inc. 2022 | Printed in Canada

If you have any comments or questions on this manual, or find an error, email us at comments@aggrowth.com.
Please include the part number listed on the cover page in your message.