



A = 6" Electric Distributor 60°

No. Of Outlets	B	C	D	E	F	H
4	55	38 1/2	31	37	18	26
6	55	38 1/2	31	37	18	26
8	55	38 1/2	31	37	18	26
10	57	48 1/2	41	45 1/2	11 1/2	26
12	57	48 1/2	41	45 1/2	11 1/2	26
14	62 1/2	55 1/2	48	51 1/2	11	30
16	74 1/4	63 1/2	56	58 1/2	15 3/4	36
18	81	71 1/2	64	65 1/2	15 1/2	42

A = 8" Electric Distributor 60°

No. Of Outlets	B	C	D	E	F	H
4	57	40	31	37	20	26
6	57	40	31	37	20	26
8	57 1/4	50	41	45 1/2	11 3/4	26
10	57 1/4	50	41	45 1/2	11 3/4	26
12	63	57	48	51 1/2	11 1/2	28
14	70	65	56	58 1/2	11 1/2	36
16	82	73	64	65 1/2	16 1/2	44
18	87	79	70	70 1/2	16 1/2	48

A = 10" Electric Distributor 60°

No. Of Outlets	B	C	D	E	F	H
4	59	42	31	37	22	26
6	59	42	31	37	22	26
8	63	52	41	45 1/2	17 1/2	26
10	63 1/2	59	48	51 1/2	12	26
12	70 1/2	67	56	58 1/2	12	34
14	77 1/2	75	64	65 1/2	12	42
16	90	84	73	73 1/4	16 3/4	50
18	80 5/8	92	81	80 1/8	23	32

A = 12" Electric Distributor 60°

No. Of Outlets	B	C	D	E	F	H
4	65	54 1/4	41	45 1/2	19 1/2	26
6	65	54 1/4	41	45 1/2	19 1/2	26
8	64 1/4	61 1/4	48	51 1/2	12 3/4	26
10	71	69 1/4	56	58 1/2	12 1/2	32
12	78	77 1/4	64	65 1/2	12 1/2	40
14	91	86 1/4	73	73 1/4	17 3/4	48
16	99 1/2	96 1/4	83	82	17 1/2	58
18	124 1/4	115 1/4	102	98	26 1/4	78