



A475 Hopper Cover

Portable U-Trough Grain Auger Installation Instructions

Applicable Models:

UTX

Pre-Installation

Before installing the hopper tarp cover, lower the collapsible hopper.

Installation



Step 1


- Loop the hopper tarp support through the integrated strap.
- The widely spaced eyelets should be at the front of the hopper, while the narrowly spaced eyelets should be installed at the back.

1	Hopper Tarp Support
2	UTX Hopper Cover with Bungees
3	Strap



Step 2

- Install the tarp support by hooking it onto the hopper mesh.
- The tarp support should be installed slightly off center towards the front of the hopper.



Step 3

- Hook the cover over the front corners as low as possible.
- The cover has four corners with a bungee cord sewn to fit snug around the front.



Step 4

- Hook the cover over the springs at the sides of the hopper.



Step 5

- Install the long bungee cord around the back of the hopper by hooking it into the eyelets of the cover.



Step 6

- Install the short bungee cord at the front of the hopper by looping through the two hopper handles and hooking into the eyelets of the cover.
- Ensure the cover is fitted properly over the hopper and the tarp support is standing.



P.O. Box 39
Rosenort, Manitoba, R0G 1W0 Canada
Phone: (866) 467-7207 (Canada & USA) or (204) 746-2396
Fax: (866) 768-4852

Website: www.grainaugers.com

Email: sales@grainaugers.com

©Ag Growth International Inc. 2020, Printed in Canada